



MODEL CH-10, CH-10AL

REPAIR PARTS

No.	Description	Part No.	No.	Description	Part No.
1.	Airtank	N/A	8.	90° NPT	03.104
2.	Pipe Nipple	02.104	9.	Safety Release Valve	05.102
3*	Discharge Valve (Includes Handle)	03.102	10.	Handle & Nut Only	01.230
4.	Lock Nut	03.107	11.	Ball Valve	04.103
5.	Threaded Barrel	03.103	12.	Rubber Feet	12607
6.	200 PSI Gauge	01.106			
7.	3/4" - 1/4" Bushing	01.107			

Reminder: Always exercise caution when using compressed air.

PCL Connector is **NOT INCLUDED** must be purchased separately.

Order parts from your distributor or jobber.
When ordering parts always give the following information: Part number, description and serial number of your machine.

